



Dr. Vishwanath Karad
MIT WORLD PEACE
UNIVERSITY | PUNE
TECHNOLOGY, RESEARCH, SOCIAL INNOVATION & PARTNERSHIPS

School of Electronics and Communication Engineering
Academic Year 2020 - 2021

Mini Project Report - Trimester VI

Natural Sampling Theorem

Analog Communication

Student details:

Sr. No	PRN	Student Name	Contact No	Email Id
1	1032191005	Rohan Habu	8983117939	haburohan@gmail.com
2	1032191053	Mehul Verma	8454097831	mehul2001.mit@gmail.com
3	1032191177	Vishal Singh	8287676489	vs978886@gmail.com

Circuit Diagram





Figure 1: Sampling Circuit

GUI Layout Screenshot



Introduction

- This GUI implements the concept of natural sampling process.
- Natural sampling process includes multiplication of impulse signal to the original signal to be sampled.
- The pulse width is negligible.
- Thus, at the output, straight lines called samples are received.
- There are also other techniques like sample and hold and flat top sampling.
- Practically the width can't be zero.
- So, there is some portion present but it is unnoticeable by naked eyes.
- In this process, we take the impulse signal and its pulse width is 0% percent of the amplitude of impulse in MATLAB.
- In this manner a train of impulses can be generated at different frequencies.
- Suppose consider an example of a variable sine wave.
- It can reach up to highest amplitude of 5V and highest frequency of 10Hz.
- So, we need to generate an impulse of amplitude 5V minimum or slightly greater than this to properly sample the wave aligning on the Y Axis.
- In the train of impulses, we need to carefully select the frequency of the impulses occurring.
- According to the impulse/ sampling frequency selection, the sampling process can be distributed in to following categories:
 - Under sampling.
 - Critical sampling (Nyquist sampling).
 - Over sampling.
- Here, oversampling is the most useful case to sample the input signal.
- Critical sampling is the point at which you just get the nature of the wave that is fed in to the circuit.
- After critical sampling case, the oversampling case begins and the sampled wave gets more closer to the wave at the input.
- In under sampling, the frequency bands of the impulses overlap with each other.
- This changes the nature of the signal at the output.
- Also, due to overlapping of bands, it is common to 2 adjacent signals and due to this, a phenomenon, or an error in case of communication occurs which is called as aliasing.
- It means that a band is common for 2 signals at the same time which disturbs the nature of the signal during sampling process.
- Let f_s =sampling frequency.
- f_m =maximum frequency of the signal at the input.
- Under sampling condition:
 $f_s < f_m$

- Critical/Nyquist sampling:
 $f_s = 2f_m$
- Oversampling condition:
 $f_s \gg 2f_m$
- So, to avoid aliasing effect and the disturbance in the output of the signal, oversampling method is used everywhere.

Description of the GUI

So, the GUI has ability of generating the sine, square, triangular and saw tooth types of waves. There is a choice given to the user for selecting an appropriate wave to generate and perform sampling operation on the desired sampling rate. User also can select the required amplitude, frequency, phase, and duty cycle for the waves. Also, the sampling rate can be chosen by the choice of the user. The maximum limit for amplitude, frequency and phase in the GUI is 100.


Applications

Sampling theorem has various applications in real life: -


1. Mobile phones and laptops for communication.
2. Bluetooth speakers.
3. Television broadcasting on internet.
4. To study the signal in discrete domain and remove discontinuities in the signal.
5. Used in smart wearables (smart watches, fitness bands, etc.)

OUTPUTS


SINE WAVE UNDER SAMPLED




SINE WAVE CRITICALLY SAMPLED




SINE WAVE OVER SAMPLED




SQUARE WAVE UNDER SAMPLED




SQUARE WAVE CRITICALLY SAMPLED




SQUARE WAVE OVER SAMPLED




TRIANGULAR WAVE UNDER SAMPLED




TRIANGULAR WAVE CRITICALLY SAMPLED




TRIANGULAR WAVE OVER SAMPLED




SAW TOOTH WAVE UNDER SAMPLED



SAW TOOTH WAVE CRITICALLY SAMPLED



SAW TOOTH WAVE OVER SAMPLED



PROGRAM

```
classdef samplingGUI < matlab.apps.AppBase
```

```
% Properties that correspond to app components
```

```
properties (Access = public)
```

UIFigure	matlab.ui.Figure
AmplitudeKnobLabel	matlab.ui.control.Label
AmplitudeKnob	matlab.ui.control.Knob
FrequencyKnobLabel	matlab.ui.control.Label
FrequencyKnob	matlab.ui.control.Knob
PhaseKnobLabel	matlab.ui.control.Label
PhaseKnob	matlab.ui.control.Knob
DutyCycleKnobLabel	matlab.ui.control.Label
DutyCycleKnob	matlab.ui.control.Knob
SamplingRateKnobLabel	matlab.ui.control.Label
SamplingRateKnob	matlab.ui.control.Knob
SelectAnywaveListBoxLabel	matlab.ui.control.Label
SelectAnywaveListBox	matlab.ui.control.ListBox
VerticalSliderLabel	matlab.ui.control.Label
VerticalSlider	matlab.ui.control.Slider
Image	matlab.ui.control.Image
MADEBYTextAreaLabel	matlab.ui.control.Label
MADEBYTextArea	matlab.ui.control.TextArea
UnderButton	matlab.ui.control.Button
CriticalButton	matlab.ui.control.Button
OverButton	matlab.ui.control.Button
SamplingTypeLabel	matlab.ui.control.Label
AnalogCommunicationGroupActivityLabel	matlab.ui.control.Label
UnderGuidanceOfLabel	matlab.ui.control.Label
MrsSumitraMotadeLabel	matlab.ui.control.Label
NATURALSAMPLINGTHEOREMLabel	matlab.ui.control.Label
SYBTechDIVCLabel	matlab.ui.control.Label
UIAxes	matlab.ui.control.UIAxes
UIAxes2	matlab.ui.control.UIAxes
UIAxes3	matlab.ui.control.UIAxes

```
End
```

properties (Access = private)

time
samplingTime
sampleRate
sineamp % Description
sinefre
sineph
sinewave
sqamp
sqfre
sqduty
sqwave
triamp
trifre
triwave
sawamp
sawfre
sawduty
sawwave
sampledSine
sampledSq
sampledTri
sampledSaw
undersampledAmp
undersampledFre
undersampledPh
undersampledDc
undersampledSine
undersampledSq
undersampledTri
undersampledSaw
undersamplingtime
criticalsampledAmp
criticalsampledFre
criticalsampledPh
criticalsampledDc
CriticalsampledSine
criticalsampledSq
criticalsampledTri
CriticalsampledSaw
criticalsamplingtime
oversampledAmp
OversampledFre

```

oversampledPh
OversampledDc
oversampledSine
oversampledSq
oversampledTri
oversampledSaw
oversamplingtime
End
% Callbacks that handle component events
methods (Access = private)
    % Code that executes after component creation
    function startupFcn(app)
        app.SamplingRateKnob.Value=1;
        app.sampleRate=app.SamplingRateKnob.Value;
        app.samplingTime=linspace(0,1,app.sampleRate);
    end
    % Value changed function: SelectAnywaveListBox
    function SelectAnywaveListBoxValueChanged(app, event)
        value = app.SelectAnywaveListBox.Value;
        switch value
            case 'Sine'
                app.VerticalSlider.Value=1;
                app.sineamp=1;
                app.sinefre=1;
                app.sineph=0;
                app.time=linspace(0,1,1000);
                app.sinewave=app.sineamp*sin(2*pi*app.time*app.sinefre+app.sineph);
                app.sampledSine=app.sineamp*sin(2*pi*app.sinefre*app.samplingTime+app.sineph);
                plot(app.UIAxes,app.time,app.sinewave);
                stem(app.UIAxes2,app.samplingTime,app.sampledSine);
                ylim(app.UIAxes,[-1,1]);
                ylim(app.UIAxes2,[-1,1]);
                app.DutyCycleKnob.Value=0.5;
                app.DutyCycleKnob.Enable=0;
                app.AmplitudeKnob.Value=1;
                app.FrequencyKnob.Value=1;
                app.PhaseKnob.Enable=1;
                app.PhaseKnob.Value=0;
            case 'Square'
                app.VerticalSlider.Value=1;
                app.sqamp=1;
                app.sqfre=1;
                app.time=linspace(0,1,1000);
                app.sqduty=0.5*100;

```

```

app.sqwave=app.sqamp*square(2*pi*app.sqfre*app.time);
app.sampledSq=app.sqamp*square(2*pi*app.sqfre*app.samplingTime,app.sqduty);
plot(app.UIAxes,app.time,app.sqwave);
stem(app.UIAxes2,app.samplingTime,app.sampledSq);
ylim(app.UIAxes,[-1,1]);
ylim(app.UIAxes2,[-1,1]);
app.DutyCycleKnob.Enable=1;
app.DutyCycleKnob.Value=0.5;
app.AmplitudeKnob.Value=1;
app.FrequencyKnob.Value=1;
app.PhaseKnob.Enable=0;
app.PhaseKnob.Value=0;
case 'Triangle'
app.VerticalSlider.Value=1;
app.trifre = 1;
app.triamp=1;
app.time =linspace(0,1,1000);
app.triwave = app.triamp*sawtooth(2*pi*app.trifre*app.time,1/2);
app.sampledTri = app.triamp*sawtooth(2*pi*app.samplingTime*app.trifre,1/2);
plot(app.UIAxes,app.time,app.triwave);
stem(app.UIAxes2,app.samplingTime,app.sampledTri);
ylim(app.UIAxes,[-1,1]);
ylim(app.UIAxes2,[-1,1]);
app.DutyCycleKnob.Enable=0;
app.DutyCycleKnob.Value=0.5;
app.AmplitudeKnob.Value=1;
app.FrequencyKnob.Value=1;
app.PhaseKnob.Enable=0;
app.PhaseKnob.Value=0;
case 'Sawtooth'
app.VerticalSlider.Value=1;
app.sawfre=1;
app.time=linspace(0,1,1000);
app.sawduty=1;
app.sawamp=1;
app.sawwave=app.sawamp*sawtooth(2*pi*app.sawfre*app.time);
app.sampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.samplingTime,app.sawduty);
plot(app.UIAxes,app.time,app.sawwave);
stem(app.UIAxes2,app.samplingTime,app.sampledSaw);
ylim(app.UIAxes,[-1,1]);
ylim(app.UIAxes2,[-1,1]);
app.DutyCycleKnob.Enable=1;
app.DutyCycleKnob.Value=0.5;
app.AmplitudeKnob.Value=1;

```

```

    app.FrequencyKnob.Value=1;
    app.PhaseKnob.Enable=0;
    app.PhaseKnob.Value=0;
end
end
% Value changing function: AmplitudeKnob
function AmplitudeKnobValueChanging(app, event)
    value = event.Value;
    switch app.SelectAnywaveListBox.Value
    case 'Sine'
        app.sineamp=value;
        app.sinewave=app.sineamp*sin(2*pi*app.time*app.sinefre+app.sineph);
        app.sampledSine=app.sineamp*sin(2*pi*app.sinefre*app.samplingTime+app.sineph);
        plot(app.UIAxes,app.time,app.sinewave);
        stem(app.UIAxes2,app.samplingTime,app.sampledSine);
    case 'Square'
        app.sqamp=value;
        app.sqwave=app.sqamp*square(2*pi*app.sqfre*app.time);
        app.sampledSq=app.sqamp*square(2*pi*app.sqfre*app.samplingTime,app.sqduty);
        plot(app.UIAxes,app.time,app.sqwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledSq);
    case 'Triangle'
        app.triamp=value;
        app.triwave = app.triamp*sawtooth(2*pi*app.trifre*app.time,1/2);
        app.sampledTri = app.triamp*sawtooth(2*pi*app.samplingTime*app.trifre,1/2);
        plot(app.UIAxes,app.time,app.triwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledTri);
    case 'Sawtooth'
        app.sawamp=value;
        app.sawwave=app.sawamp*sawtooth(2*pi*app.sawfre*app.time);
        app.sampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.samplingTime,app.sawduty);
        plot(app.UIAxes,app.time,app.sawwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledSaw);
    end
end
% Value changing function: FrequencyKnob
function FrequencyKnobValueChanging(app, event)
    value = event.Value;
    switch app.SelectAnywaveListBox.Value
    case 'Sine'
        app.sinefre=value;
        app.sinewave=app.sineamp*sin(2*pi*app.time*app.sinefre+app.sineph);
        app.sampledSine=app.sineamp*sin(2*pi*app.sinefre*app.samplingTime+app.sineph);
        plot(app.UIAxes,app.time,app.sinewave);

```

```

        stem(app.UIAxes2,app.samplingTime,app.sampledSine);
    case 'Square'
        app.sqfre=value;
        app.sqwave=app.sqamp*square(2*pi*app.sqfre*app.time);
        app.sampledSq=app.sqamp*square(2*pi*app.sqfre*app.samplingTime,app.sqduty);
        plot(app.UIAxes,app.time,app.sqwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledSq);
    case 'Triangle'
        app.trifre=value;
        app.triwave = app.triamp*sawtooth(2*pi*app.trifre*app.time,1/2);
        app.sampledTri = app.triamp*sawtooth(2*pi*app.samplingTime*app.trifre,1/2);
        plot(app.UIAxes,app.time,app.triwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledTri);
    case 'Sawtooth'
        app.sawfre=value;
        app.sawwave=app.sawamp*sawtooth(2*pi*app.sawfre*app.time);
        app.sampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.samplingTime,app.sawduty);
        plot(app.UIAxes,app.time,app.sawwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledSaw);
    end
end
% Value changing function: PhaseKnob
function PhaseKnobValueChanging(app, event)
    value = event.Value;
    switch app.SelectAnywaveListBox.Value
        case 'Sine'
            app.sineph=value;
            app.sinewave=app.sineamp*sin(2*pi*app.time*app.sinefre+app.sineph);
            app.sampledSine=app.sineamp*sin(2*pi*app.sinefre*app.samplingTime+app.sineph);
            plot(app.UIAxes,app.time,app.sinewave);
            stem(app.UIAxes2,app.samplingTime,app.sampledSine);
        end
    end
% Value changing function: DutyCycleKnob
function DutyCycleKnobValueChanging(app, event)
    value = event.Value;
    switch app.SelectAnywaveListBox.Value
        case 'Square'
            app.sqduty=value*100;
            app.sqwave=app.sqamp*square(2*pi*app.sqfre*app.time,app.sqduty);
            app.sampledSq=app.sqamp*square(2*pi*app.sqfre*app.samplingTime,app.sqduty);
            plot(app.UIAxes,app.time,app.sqwave);
            stem(app.UIAxes2,app.samplingTime,app.sampledSq);
        case 'Sawtooth'

```



```

        app.sawduty=value;
        app.sawwave=app.sawamp*sawtooth(2*pi*app.sawfre*app.time,app.sawduty);
        app.sampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.samplingTime,app.sawduty);
        plot(app.UIAxes,app.time,app.sawwave);
        stem(app.UIAxes2,app.samplingTime,app.sampledSaw);
    end
end
% Value changing function: SamplingRateKnob
function SamplingRateKnobValueChanging(app, event)
    value = event.Value;
    app.sampleRate=value;
    switch app.SelectAnywaveListBox.Value
        case 'Sine'
            app.samplingTime=0:1/value:1;
            app.sampledSine=app.sineamp*sin(2*pi*app.sinefre*app.samplingTime+app.sineph);
            stem(app.UIAxes2,app.samplingTime,app.sampledSine);
        case 'Square'
            app.samplingTime=0:1/value:1;
            app.sampledSq=app.sqamp*square(2*pi*app.sqfre*app.samplingTime,app.sqduty);
            stem(app.UIAxes2,app.samplingTime,app.sampledSq);
        case 'Triangle'
            app.samplingTime=0:1/value:1;
            app.sampledTri = app.triamp*sawtooth(2*pi*app.samplingTime*app.trifre,1/2);
            stem(app.UIAxes2,app.samplingTime,app.sampledTri);
        case 'Sawtooth'
            app.samplingTime=0:1/value:1;
            app.sampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.samplingTime,app.sawduty);
            stem(app.UIAxes2,app.samplingTime,app.sampledSaw);
    end
end
% Value changing function: VerticalSlider
function VerticalSliderValueChanging(app, event)
    changingValue = event.Value;
    ylim(app.UIAxes,[-changingValue,changingValue]);
    ylim(app.UIAxes2,[-changingValue,changingValue]);
end
% Button pushed function: UnderButton
function UnderButtonPushed(app, event)
    value=app.SelectAnywaveListBox.Value;
    switch value
        case 'Sine'
            app.undersamplingtime=linspace(0,1,app.sinefre/2);
            app.undersampledSine=app.sineamp*sin(2*pi*app.sinefre*app.undersamplingtime
+(app.sineph));

```

```

stem(app.UIAxes3,app.undersamplingtime,app.undersampledSine);
title(app.UIAxes3,'Under Sampled Wave fs=fm/2');
case 'Square'
app.undersamplingtime=linspace(0,1,app.sqfre/2);
app.undersampledSq=app.sqamp*square(2*pi*app.sqfre*app.undersamplingtime,app.sqduty);
stem(app.UIAxes3,app.undersamplingtime,app.undersampledSq);
title(app.UIAxes3,'Under Sampled Wave fs=fm/2');
case 'Triangle'
app.undersamplingtime=linspace(0,1,app.trifre/2);
app.undersampledTri = app.triamp*sawtooth(2*pi*app.undersamplingtime*app.trifre,1/2);
stem(app.UIAxes3,app.undersamplingtime,app.undersampledTri);
title(app.UIAxes3,'Under Sampled Wave fs=fm/2');
case 'Sawtooth'
app.undersamplingtime=linspace(0,1,app.sawfre/2);
app.undersampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.undersamplingtime,app.sawduty);
stem(app.UIAxes3,app.undersamplingtime,app.undersampledSaw);
title(app.UIAxes3,'Under Sampled Wave fs=fm/2');
end
end
% Button pushed function: CriticalButton
function CriticalButtonPushed(app, event)
value=app.SelectAnywaveListBox.Value;
switch value
case 'Sine'
app.criticalsamplingtime=linspace(0,1,2*app.sinefre);
app.criticalsampledSine=app.sineamp*sin(2*pi*app.sinefre*app.criticalsamplingtime+(app.sineph));
stem(app.UIAxes3,app.criticalsamplingtime,app.criticalsampledSine);
title(app.UIAxes3,'Critical Sampled Wave fs=2*fm');
case 'Square'
app.criticalsamplingtime=linspace(0,1,2*app.sqfre);
app.criticalsampledSq=app.sqamp*square(2*pi*app.sqfre*app.criticalsamplingtime,app.sqduty);
stem(app.UIAxes3,app.criticalsamplingtime,app.criticalsampledSq);
title(app.UIAxes3,'Critical Sampled Wave fs=2*fm');
case 'Triangle'
app.criticalsamplingtime=linspace(0,1,2*app.trifre);
app.criticalsampledTri = app.triamp*sawtooth(2*pi*app.criticalsamplingtime*app.trifre,1/2);
stem(app.UIAxes3,app.criticalsamplingtime,app.criticalsampledTri);
title(app.UIAxes3,'Critical Sampled Wave fs=2*fm');
case 'Sawtooth'
app.criticalsamplingtime=linspace(0,1,app.sawfre*2);
app.criticalsampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.criticalsamplingtime,app.sawduty);
stem(app.UIAxes3,app.criticalsamplingtime,app.criticalsampledSaw);
title(app.UIAxes3,'Critical Sampled Wave fs=2*fm');

```

```

        end
    end
% Button pushed function: OverButton
    function OverButtonPushed(app, event)
        value=app.SelectAnywaveListBox.Value;
        switch value
            case 'Sine'
                app.oversamplingtime=linspace(0,1,10*app.sinefre);
                app.oversampledSine=app.sineamp*sin(2*pi*app.sinefre*app.oversamplingtime
+(app.sineph));
                stem(app.UIAxes3,app.oversamplingtime,app.oversampledSine);
                title(app.UIAxes3,'Over Sampled Wave fs=10*fm');
            case 'Square'
                app.oversamplingtime=linspace(0,1,10*app.sqfre);
                app.oversampledSq=app.sqamp*square(2*pi*app.sqfre*app.oversamplingtime,app.sqduty);
                stem(app.UIAxes3,app.oversamplingtime,app.oversampledSq);
                title(app.UIAxes3,'Over Sampled Wave fs=10*fm');
            case 'Triangle'
                app.oversamplingtime=linspace(0,1,10*app.trifre);
                app.oversampledTri = app.triamp*sawtooth(2*pi*app.oversamplingtime*app.trifre,1/2);
                stem(app.UIAxes3,app.oversamplingtime,app.oversampledTri);
                title(app.UIAxes3,'Over Sampled Wave fs=10*fm');
            case 'Sawtooth'
                app.oversamplingtime=linspace(0,1,10*app.sawfre);
                app.oversampledSaw=app.sawamp*sawtooth(2*pi*app.sawfre*app.oversamplingtime,app.sawduty);
                stem(app.UIAxes3,app.oversamplingtime,app.oversampledSaw);
                title(app.UIAxes3,'Over Sampled Wave fs=10*fm');
            end
        end
    end
end
% Component initialization
methods (Access = private)
    % Create UIFigure and components
    function createComponents(app)
        % Create UIFigure and hide until all components are created
        app UIFigure = uifigure('Visible', 'off');
        app UIFigure.AutoResizeChildren = 'off';
        app UIFigure.Color = [0 1 1];
        app UIFigure.Position = [100 100 1180 574];
        app UIFigure.Name = 'MATLAB App';
        app UIFigure.Resize = 'off';
        % Create AmplitudeKnobLabel
        app.AmplitudeKnobLabel = uilabel(app UIFigure);
        app.AmplitudeKnobLabel.HorizontalAlignment = 'center';

```

```

app.AmplitudeKnobLabel.Position = [79 283 59 22];
app.AmplitudeKnobLabel.Text = 'Amplitude';
% Create AmplitudeKnob
app.AmplitudeKnob = uiknob(app.UIFigure, 'continuous');
app.AmplitudeKnob.Limits = [1 100];
app.AmplitudeKnob.MajorTicks = [1 10 20 30 40 50 60 70 80 90 100];
app.AmplitudeKnob.MajorTickLabels = {'1', '10', '20', '30', '40', '50', '60', '70', '80', '90', '100'};
app.AmplitudeKnob.ValueChangingFcn = createCallbackFcn(app,
@AmplitudeKnobValueChanging, true);
app.AmplitudeKnob.Position = [77 339 60 60];
app.AmplitudeKnob.Value = 1;
% Create FrequencyKnobLabel
app.FrequencyKnobLabel = uilabel(app.UIFigure);
app.FrequencyKnobLabel.HorizontalAlignment = 'center';
app.FrequencyKnobLabel.Position = [211 283 62 22];
app.FrequencyKnobLabel.Text = 'Frequency';
% Create FrequencyKnob
app.FrequencyKnob = uiknob(app.UIFigure, 'continuous');
app.FrequencyKnob.Limits = [1 100];
app.FrequencyKnob.MajorTicks = [1 10 20 30 40 50 60 70 80 90 100];
app.FrequencyKnob.ValueChangingFcn = createCallbackFcn(app,
@FrequencyKnobValueChanging, true);
app.FrequencyKnob.Position = [212 339 60 60];
app.FrequencyKnob.Value = 1;
% Create PhaseKnobLabel
app.PhaseKnobLabel = uilabel(app.UIFigure);
app.PhaseKnobLabel.HorizontalAlignment = 'center';
app.PhaseKnobLabel.Position = [347 280 39 22];
app.PhaseKnobLabel.Text = 'Phase';
% Create PhaseKnob
app.PhaseKnob = uiknob(app.UIFigure, 'continuous');
app.PhaseKnob.Limits = [0 360];
app.PhaseKnob.MajorTicks = [0 30 60 90 120 150 180 210 240 270 300 330 360];
app.PhaseKnob.ValueChangingFcn = createCallbackFcn(app, @PhaseKnobValueChanging, true);
app.PhaseKnob.Position = [336 336 60 60];
% Create DutyCycleKnobLabel
app.DutyCycleKnobLabel = uilabel(app.UIFigure);
app.DutyCycleKnobLabel.HorizontalAlignment = 'center';
app.DutyCycleKnobLabel.Position = [141 115 63 22];
app.DutyCycleKnobLabel.Text = 'Duty Cycle';
% Create DutyCycleKnob
app.DutyCycleKnob = uiknob(app.UIFigure, 'continuous');
app.DutyCycleKnob.Limits = [0 1];
app.DutyCycleKnob.MajorTicks = [0 0.1 0.2 0.3 0.4 0.5 0.6 0.7 0.8 0.9 1];

```

```

    app.DutyCycleKnob.ValueChangingFcn = createCallbackFcn(app,
    @DutyCycleKnobValueChanging, true);
    app.DutyCycleKnob.Position = [142 171 60 60];
    % Create SamplingRateKnobLabel
    app.SamplingRateKnobLabel = uilabel(app.UIFigure);
    app.SamplingRateKnobLabel.HorizontalAlignment = 'center';
    app.SamplingRateKnobLabel.Position = [274 115 84 22];
    app.SamplingRateKnobLabel.Text = 'Sampling Rate';
    % Create SamplingRateKnob
    app.SamplingRateKnob = uiknob(app.UIFigure, 'continuous');
    app.SamplingRateKnob.Limits = [1 1000];
    app.SamplingRateKnob.MajorTicks = [1 100 200 300 400 500 600 700 800 900 1000];
    app.SamplingRateKnob.ValueChangingFcn = createCallbackFcn(app,
    @SamplingRateKnobValueChanging, true);
    app.SamplingRateKnob.MinorTicks = [];
    app.SamplingRateKnob.Position = [286 171 60 60];
    app.SamplingRateKnob.Value = 1;
    % Create SelectAnywaveListBoxLabel
    app.SelectAnywaveListBoxLabel = uilabel(app.UIFigure);
    app.SelectAnywaveListBoxLabel.HorizontalAlignment = 'right';
    app.SelectAnywaveListBoxLabel.Position = [52 492 94 22];
    app.SelectAnywaveListBoxLabel.Text = 'Select Any wave';
    % Create SelectAnywaveListBox
    app.SelectAnywaveListBox = uilistbox(app.UIFigure);
    app.SelectAnywaveListBox.Items = {'Sine', 'Square', 'Triangle', 'Sawtooth'};
    app.SelectAnywaveListBox.ValueChangedFcn = createCallbackFcn(app,
    @SelectAnywaveListBoxValueChanged, true);
    app.SelectAnywaveListBox.BackgroundColor = [0 1 1];
    app.SelectAnywaveListBox.Position = [161 442 100 74];
    app.SelectAnywaveListBox.Value = 'Sine';
    % Create VerticalSliderLabel
    app.VerticalSliderLabel = uilabel(app.UIFigure);
    app.VerticalSliderLabel.HorizontalAlignment = 'right';
    app.VerticalSliderLabel.Position = [406 124 45 22];
    app.VerticalSliderLabel.Text = 'Vertical';
    % Create VerticalSlider
    app.VerticalSlider = uislider(app.UIFigure);
    app.VerticalSlider.Limits = [1 100];
    app.VerticalSlider.Orientation = 'vertical';
    app.VerticalSlider.ValueChangingFcn = createCallbackFcn(app, @VerticalSliderValueChanging,
true);
    app.VerticalSlider.Position = [472 133 3 334];
    app.VerticalSlider.Value = 1;
    % Create Image
    app.Image = uiimage(app.UIFigure);

```

```

app.Image.Position = [977 -13 205 100];
app.Image.ImageSource = 'Capture.PNG';
% Create MADEBYTextAreaLabel
app.MADEBYTextAreaLabel = uilabel(app.UIFigure);
app.MADEBYTextAreaLabel.BackgroundColor = [0 1 1];
app.MADEBYTextAreaLabel.HorizontalAlignment = 'right';
app.MADEBYTextAreaLabel.FontSize = 25;
app.MADEBYTextAreaLabel.Position = [757 540 132 31];
app.MADEBYTextAreaLabel.Text = 'MADE BY:-';
% Create MADEBYTextArea
app.MADEBYTextArea = uitextarea(app.UIFigure);
app.MADEBYTextArea.FontSize = 25;
app.MADEBYTextArea.BackgroundColor = [0 1 1];
app.MADEBYTextArea.Position = [904 475 278 98];
SINGH app.MADEBYTextArea.Value = {'PC 15 ROHAN HABU'; 'PC 18 MEHUL VERMA'; 'PC 28 VISHAL
    };
% Create UnderButton
app.UnderButton = uibutton(app.UIFigure, 'push');
app.UnderButton.ButtonPushedFcn = createCallbackFcn(app, @UnderButtonPushed, true);
app.UnderButton.Position = [848 304 100 22];
app.UnderButton.Text = 'Under';
% Create CriticalButton
app.CriticalButton = uibutton(app.UIFigure, 'push');
app.CriticalButton.ButtonPushedFcn = createCallbackFcn(app, @CriticalButtonPushed, true);
app.CriticalButton.Position = [948 304 100 22];
app.CriticalButton.Text = 'Critical';
% Create OverButton
app.OverButton = uibutton(app.UIFigure, 'push');
app.OverButton.ButtonPushedFcn = createCallbackFcn(app, @OverButtonPushed, true);
app.OverButton.Position = [1048 304 100 22];
app.OverButton.Text = 'Over';
% Create SamplingTypeLabel
app.SamplingTypeLabel = uilabel(app.UIFigure);
app.SamplingTypeLabel.Position = [954 337 86 22];
app.SamplingTypeLabel.Text = 'Sampling Type';
% Create AnalogCommunicationGroupActivityLabel
app.AnalogCommunicationGroupActivityLabel = uilabel(app.UIFigure);
app.AnalogCommunicationGroupActivityLabel.FontSize = 25;
app.AnalogCommunicationGroupActivityLabel.Position = [311 539 434 31];
app.AnalogCommunicationGroupActivityLabel.Text = 'Analog Communication Group Activity';
% Create UnderGuidanceOfLabel
app.UnderGuidanceOfLabel = uilabel(app.UIFigure);
app.UnderGuidanceOfLabel.FontSize = 20;
app.UnderGuidanceOfLabel.Position = [954 443 177 24];
app.UnderGuidanceOfLabel.Text = 'Under Guidance Of';

```

```

% Create MrsSumitraMotadeLabel
app.MrsSumitraMotadeLabel = uilabel(app.UIFigure);
app.MrsSumitraMotadeLabel.FontSize = 20;
app.MrsSumitraMotadeLabel.Position = [948 419 192 24];
app.MrsSumitraMotadeLabel.Text = 'Mrs. Sumitra Motade';
% Create NATURALSAMPLINGTHEOREMLabel
app.NATURALSAMPLINGTHEOREMLabel = uilabel(app.UIFigure);
app.NATURALSAMPLINGTHEOREMLabel.HorizontalAlignment = 'center';
app.NATURALSAMPLINGTHEOREMLabel.FontSize = 25;
app.NATURALSAMPLINGTHEOREMLabel.FontWeight = 'bold';
app.NATURALSAMPLINGTHEOREMLabel.Position = [311 500 419 31];
app.NATURALSAMPLINGTHEOREMLabel.Text = 'NATURAL SAMPLING THEOREM';
% Create SYBTechDIVCLLabel
app.SYBTechDIVCLLabel = uilabel(app.UIFigure);
app.SYBTechDIVCLLabel.FontSize = 25;
app.SYBTechDIVCLLabel.Position = [41 530 200 31];
app.SYBTechDIVCLLabel.Text = 'S.Y. BTech DIV C';
% Create UIAxes
app.UIAxes = uiaxes(app.UIFigure);
title(app.UIAxes, 'Wave')
xlabel(app.UIAxes, {'Time'; ''})
ylabel(app.UIAxes, 'Amplitude')
zlabel(app.UIAxes, 'Z')
app.UIAxes.GridLineStyle = '--';
app.UIAxes.Color = [0.8 0.8 0.8];
app.UIAxes.GridColor = [0 0 1];
app.UIAxes.MinorGridColor = [1 0.0745 0.651];
app.UIAxes.Position = [525 304 300 185];
% Create UIAxes2
app.UIAxes2 = uiaxes(app.UIFigure);
title(app.UIAxes2, 'Sampled Wave')
xlabel(app.UIAxes2, 'Time')
ylabel(app.UIAxes2, 'Amplitude')
zlabel(app.UIAxes2, 'Z')
app.UIAxes2.Color = [0.8 0.8 0.8];
app.UIAxes2.Position = [524 115 300 185];
% Create UIAxes3
app.UIAxes3 = uiaxes(app.UIFigure);
title(app.UIAxes3, 'Condition Sampled Wave')
xlabel(app.UIAxes3, 'Time')
ylabel(app.UIAxes3, 'Amplitude')
zlabel(app.UIAxes3, 'Z')
app.UIAxes3.Color = [0.8 0.8 0.8];
app.UIAxes3.Position = [848 115 300 185];

```

```

        % Show the figure after all components are created
        app UIFigure.Visible = 'on';
    end
end
% App creation and deletion
methods (Access = public)
    % Construct app
    function app = samplingGUI
% Create UIFigure and components
        createComponents(app)
        % Register the app with App Designer
        registerApp(app, app UIFigure)
        % Execute the startup function
        runStartupFcn(app, @startupFcn)
        if nargin == 0
            clear app
        end
    end
end
% Code that executes before app deletion
function delete(app)
    % Delete UIFigure when app is deleted
    delete(app UIFigure)
end
end
end
end

```

REFERENCES

www.sciencedirect.com

www.tutorialspoint.com

www.mathworks.com

www.cnx.org

www.musicweb.ucsd.edu